

## **BAIL UNIT CONTROLLER Switch replacement instruction**

- Disconnect the power
- Remove the plastic box cover (four big plastic screws)
- Open the stainless steel panel
- Disconnect the old switch from the top two terminals of the circuit board
- Unscrew the switch from case and remove
- Fit new switch so the writing is visable and the OFF is "up" and ON is "down" as in the picture, the lock washer should be inside the box
- Fit Boot to switch the threadand screw on fully
- Tighten the back nut with long nose pliers (not much room between switch and case)
- Connect the wires to the two top circit board connectors (red wire top black second)
- Secure loose wires with cable ties
- Replace the plastic box cover (four big plastic screws)
- Reconect power and check that <u>run light is on</u> when switch is down



